

Remote Sounder

Part No. **NC888D**



Overview

- Can be connected to any multi-zone 800 Series Call Controller, Master Indicator Panel or Switchable Sounder to increase call indication levels.
- Indicates Standard calls via a constant tone and Emergency calls via a pulsing tone.
- No more than two remote sounders should be connected to the hosting device.
- When connected to an NC887D Switchable Sounder, switching the NC887D off will also disable any remote sounders connected to it.



Technical Specifications

Quiescent current	0mA (none).
Alarm current	Determined by the type of control equipment and number / type of field devices connected to the system.
Indicators	None.
Controls	None (the device is controlled by the host device it is connected to).
Connections	-Ve (Negative); +Ve (Positive).
Onboard Sounder	Yes. Sounds constantly for standard calls, intermittently for emergency calls.
Onboard Infrared Receiver	No.
Product dimensions (mm)	87 W x 87 H x 23 D mm. Mounts on a UK 25mm single gang back box.
Construction & finish	Plastic.
IP Rating	IP41.
Weight	66g.
Operating conditions/temperature	-5°C to +40°C. Max. relative humidity 95% non-condensing.



Notes

When connected to an NC887D Switchable Sounder, switching the NC887D off will also disable any NC888D remote sounders connected to it.

